

LUXX Comfort 2D Zero Gravity Massage Chair

User Manual

Table of Contents

1. Welcome to Luxx
 2. Safety Instructions
 3. Product Overview
 4. Getting Started
 5. Automatic Massage Programs
 6. Manual Functions
 7. Advanced Features
 8. Maintenance and Cleaning
 9. Troubleshooting
 10. Specifications
 11. Warranty and Support
-

1. Welcome to Luxx

Thank you for choosing the **Luxx Comfort 2D Zero Gravity Massage Chair**! Designed for relaxation and simplicity, this chair is perfect for anyone looking to unwind and enjoy a professional-quality massage at home. With its 2D technology, customizable settings, and zero-gravity functionality, this chair ensures you experience maximum comfort and wellness.

This manual will guide you through setup, operation, and maintenance to help you get the most out of your new Luxx Comfort 2D Massage Chair.

2. Safety Instructions

- **Placement:** Place the chair on a flat, stable surface and keep it away from water or extreme heat.
- **Usage:**

- Avoid use if you have open wounds, serious health conditions, or medical implants without consulting a physician.
 - Children and pets should not operate or play near the chair while it is in use.
 - **Power:** Ensure the chair is plugged into a properly grounded outlet. Unplug when not in use for extended periods.
-

3. Product Overview

Key Features

- **2D Massage Rollers:** Effective and customizable massage for your back.
 - **Air Compression System:** Adjustable airbags for shoulders, seat, and legs.
 - **Heat Therapy:** Provides warmth to the lumbar region.
 - **Zero Gravity Recline:** Promotes relaxation by reducing spinal pressure.
 - **Foot Rollers:** Adjustable speed for targeted relief.
 - **Simple Controls:** Intuitive remote control with multiple preset programs.
-

4. Getting Started

1. **Unboxing and Placement:**
 - Carefully unpack the chair and position it at least 20 inches away from walls or furniture.
 - Ensure there is easy access to a power outlet.
 2. **Power On:**
 - Connect the chair to a power source.
 - Press the **"Standby"** button on the remote to turn it on.
 3. **Recline Adjustment:**
 - Use the **"Rise"** and **"Drop"** buttons on the remote to adjust the chair's recline angle.
 4. **Zero Gravity Mode:**
 - Press the **Zero Gravity** button to recline into a position that reduces spinal pressure and maximizes comfort.
-

5. Automatic Massage Programs

The Luxx Comfort 2D offers five pre-programmed massage modes for effortless relaxation:

- **Kneading Mode:** Targets the upper back with a soothing kneading motion.
- **Massage Mode:** Combines kneading and tapping for deeper muscle relief.
- **Strong Mode:** Intense massage for a full-body experience.
- **Leisure Mode:** Gentle and calming massage for overall relaxation.
- **Sleep Mode:** Designed to help you unwind before bedtime with moderate pressure.

To activate a program:

1. Press the corresponding button on the remote control.
 2. Adjust intensity, speed, or duration if needed.
-

6. Manual Functions

For a customized massage experience:

- **Target Areas:** Select specific areas like neck, waist, or legs using the manual adjustment buttons.
 - **Roller Speed:**
 - Use the **Speed +** and **Speed -** buttons to adjust the speed of the massage rollers.
 - **Airbag Intensity:**
 - Adjust the pressure of the airbags using the **Pressure Intensity** button.
 - **Foot Rollers:**
 - Activate and adjust the foot roller speed with the **Feet Speed** button.
-

7. Advanced Features

- **Heat Therapy:**
 - Press the **Heating** button to activate lumbar heat. This feature enhances circulation and relaxes muscles.
 - **Time Adjustment:**
 - Select massage durations of **15**, **20**, **25**, or **30 minutes** using the **Time** button.
 - **Bluetooth Speakers:**
 - Pair your device via Bluetooth for music. Default password: **8888**.
-

8. Maintenance and Cleaning

- **Cleaning:**
 - Wipe the chair's exterior with a damp cloth and mild detergent. Do not soak or use abrasive cleaners.
 - **Inspection:**
 - Regularly check for loose screws or damage to rollers, airbags, or the control panel.
 - **Storage:**
 - When not in use, cover the chair to protect it from dust.
-

9. Troubleshooting

Issue	Possible Cause	Solution
Chair won't power on	Loose or disconnected cord	Check the power cord and outlet.
Airbags not inflating	Low intensity setting	Increase airbag pressure.
Foot rollers not working	Function not activated	Press the Feet Speed button.
Heat not working	Feature not toggled	Ensure the heat button is activated.
Chair not reclining	Remote not responding	Check battery or connection.

10. Specifications

Feature	Details
Upright Dimensions	40" H x 55" L x 28" W
Reclined Dimensions	32" H x 65" L x 28" W
Weight	~170 lbs
Power Supply	110-240V AC, 50-60Hz
Heating Zones	Lumbar Region
Bluetooth Range	Up to 10 meters

11. Warranty and Support

Your Luxx Vitality 4D Zero Gravity Massage Chair comes with a limited warranty covering parts and labor. For support or questions, please contact us at:

- **Phone:** 778-888-1294
- **Email:** theluxxliving@gmail.com
- **Website:** luxxmassagechairs.com